

Bar Maid®

INSTRUCTION MANUAL



COMMERCIAL CITRUS JUICER JUC-100



JUICER SAFETY



DANGER Electricity



GENERAL Caution



DANGER Risk of Electrical Shock







DANGER Keep Hands Clear



IMPORTANT: Please adhere to all safety guidelines contained in it's manual.

DANGER: You can be seriously injured if you do not follow these instructions.

 WARNING 	 WARNING 
<p>Electrical Shock Hazard</p> <p>Plug into a grounded outlet.</p> <p>Do not remove ground.</p> <p>Do not use an adapter.</p> <p>Do not use an extension cord, except as recommended.</p> <p>Failure to follow these instructions can result in death, fire or electrical shock.</p>	<p>Moving Parts!</p> <p>Always leave splashguard in place when juicing.</p> <p>Avoid direct hand contact with juicing cone.</p> <p>Failure to follow these instructions can result in broken bones, cuts or other injuries.</p>

**FAILURE TO ADHERE TO THESE WARNINGS CAN RESULT IN FIRE,
SERIOUS INJURY, ELECTRICAL SHOCK AND/OR DEATH**



WARNING



JUICING CONES ROTATE WITH SUBSTANTIAL FORCE. USE EXTREME CAUTION WHEN PRESSING FRUIT ON TO CONES. NEVER CONTACT MOVING PARTS DIRECTLY WITH HANDS.

For Warranty Assistance:

1-866-531-6243

For Parts or Technical Assistance:

(954) 960-1468

1-800-526-5278

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all the instructions.
2. To protect against risk of electrical shock, do not put the blender in water or other liquid.
3. Close supervision is necessary when any appliance is used near Children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contact with moving parts, especially blades.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination/repair /electrical or mechanical adjustment, or contact your distributor.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter.
10. Always make sure the juicing cones are free of obstructions before turning the unit on.
11. Be sure to turn switch to OFF position after each use. Make sure the motor stops completely before disassembling.
12. Do not put your fingers or other objects on the juicer cone while it operation. Turn the motor off and disassemble juicer to remove any pulp.
13. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

GROUNDING INSTRUCTIONS

This appliance should be grounded while in use to protect the operator from electrical shock. The appliance is equipped with a 3-conductor cord and a 3-prong grounding-type plug to fit the proper GFCI protected, grounding-type receptacle.

EXTENSION CORDS

Use only 3-wire extension cords which have 3-prong grounding-type plugs and 3-pole cord connectors that accept the plug from the appliance. Use only extensions cords having an electrical rating no less than the rating of the appliance. Do not use damaged extension cords. examine extension cord before using and replace if damaged. Do not abuse extension cord and do not yank on any cord to disconnect. Keep cord away from heat and sharp edges.

JUICER OPERATION

To operate the juicer, proceed as follows



Step 1. Ensure the commercial citrus juicer is cleaned thoroughly and correctly assembled with a container placed under the juice spout before juicing.



Step 2. Cut the citrus fruit in half by cutting across the diameter, and not tip to tip, to ensure more efficient juicing. For the best contact with the fruit cone, smooth the outside of the fruit by trimming any tip ends such as the ends of a lemon or tangelo .



Step 3. Plug the power cord into a properly grounded power outlet and then switch the on/off button to ON. This begins operation of the citrus juicer. The motor will start and juicing cones will rotate.



Step 4. Place citrus fruit half with the cut side down onto the juice cone. Be careful not to press too hard. Use caution not to contact moving parts with your hands.



Step 5. The juice will be extracted from the fruit and flow through the juice spout into the container. The pulp and seeds will collect in the stainless steel filter.



Step 6. The Bar Maid commercial citrus juicer juices very quickly so fruit halves will be juiced in a few seconds. To stop the motor, turn switch to off.

Step 7. Remove the used fruit from the juicing cone. Empty excess pulp and seeds from stainless steel filter as required. Repeat steps 4-7 to continue juicing.

NOTE: The stainless steel filter should be emptied when full with pulp and seeds. The filter can be emptied during juicing by switching the citrus juicer "OFF" and carefully removing the juicing cone and filter. Clean and replace stainless steel filter and juicing cone before continuing to juice. Do not allow the stainless steel filter to overfill as this may prevent correct operation or damage the unit.

CARE, CLEANING AND STORAGE

- Always ensure that the juicer is switched OFF and the plug is removed from the power outlet before cleaning, disassembling, assembling and storing the appliance .
- Follow these instructions to clean all surfaces or parts that come into contact with food during juicing:

1. Immediately after each use rinse removable parts under warm water to remove wet pulp. Allow parts to air dry before reassembling.
2. For thorough cleaning after disassembling the appliance, all removable parts should be washed in tepid soapy water or on the top shelf of the dishwasher. The motor base should be wiped with a soft, damp cloth. All parts should be dried thoroughly before reassembling. Do not place base of unit in the dishwasher.
3. Store the cleaned and reassembled citrus juicer in an upright position in a cool, dry place.
Never place any items on the top of the citrus juicer.
4. Any other servicing should be performed by an authorized service representative.

NOTES: 1. Rinse or wash all removable parts immediately after use. Dried citrus pulp is difficult to remove and may stain. If any staining does occur, wipe the affected parts with undiluted dishwashing liquid, rinse and dry thoroughly.
2. Do not soak the stainless steel filter or other removable parts in bleach. Never immerse the motor base in water or any other liquid. Do not use harsh abrasives.

TROUBLESHOOTING

Possible Problem	Easy Solution
Machine will not work	Switch not "ON"
Machine will not work	Breaker switched off
The juicing cone will not spin	Juicing cone damaged. Replace.

Replacement Parts

For replacement parts, call toll free: 1-800-526-5278



BAR MAID CORPORATION
2950 NW 22nd Terrace,
Pompano Beach, FL 33069
www.barmaidwashers.com